

ISC SURFACE GUARD APPLICATION INSTRUCTIONS

Prep

- For best results, apply at temperatures between 50°F - 80°F.
- Surface must be clean and free of dirt and/or wax prior to application.
- Use sharp scissors to cut Surface Guard to size before removing liner.
- Experiment with a small piece first.

Dry Application

- Remove paper liner slowly as Surface Guard is applied.
- Squeegee into position very slowly. The more you take your time, the better.
- Again, experiment first.

Wet Application

- Spray a mixed solution of soap and water.
- Spray the surface to be applied over. Remove the liner, apply, position into place and squeegee out the bubbles.
- Any bubbles can be punctured with a razor tip.
- Allow 24 hours for drying.

Limited Warranty

- Since a wide variety of surfaces exist, no guarantee is expressed or implied as to removability or damage to the surface.
Any material shown to be defective to ISC Racers Tape will carry a warranty implied to product replacement only.

ISC RACERS TAPE - FAIRLESS HILLS, PA 19030



